

Monthly Inspection:	
	Complete the Weekly Inspection.
	Open power box and vacuum inside. Clean exhaust fan.
	Inspect shoulder restraint release system for security and operation. Lube canopy gas strut pivot ball points with white lube.
	Apply thin coat of white lube on the bottom pin of the canopy latch spring assembly.
	Inspect the condition of the upper and lower canopy latch assembly.
	Tighten any loose screws on the fiber glass body, Cockpit and Tail assembly
	Check for loose lag bolts inside the cockpit seat to glass mounts.
	Check for the security of the A-Frame to the foundation. Look for signs of the unit walking or loose anchor bolts.
	Verify tail stand and front support did not walk. Is secure to the floor.
	Inspect the condition of all fiberglass parts.
	<p>Check the Alert log on the game computer and delete the entries.</p> <p>Click on Start, then Programs, then Explorer, open MaxFlight folder, you will see 3 items, Bin, Config and Logs. Double click on Logs. Click on Alert log.txt. Use edit, highlight all past entries you wish to delete, edit and then delete, to delete the past old text within that log.</p>
	Inspect the front stairs, fencing and entry gate for condition and cleanliness. Inspect patron que area for any unsafe conditions.
Semi-Annual	
	Clean and wax the fiberglass parts with a good car wax.
Annual	
	Lube lift motor grease fittings, one pump into each fitting only.